User Manual

Table of Contents

1. Service Structure **4**
2. User Reminder **5**
MangoSports PIN (Personal Identification Number) 5
Usage Boundary 5
Important notes on sending bets 5
Loss of MangoSports 6
Customer Services 6
Specifications 6
Battery Charging 7
MangoSports introduction 7
Maintenance 8
Functional icons 8
Services 8
Main menu 9
3. Betting Services **11**
Horse Racing - Quick Start ***12***
Race number selection / Pool selection 14
Win / Place / Win/Place 15
Quinella / QIN Place / QIN/QIN Place / Trio 15
Tierce 16
Double / Treble / Six Up 19
Double Trio / Triple Trio 19
All Up Win / All Up Place 20
All Up Qin / All Up QIN Place / All Up Trio 22
Complete betting 24
Football - Quick Start ***26***
Match date selection / Match selection 28
Bet type selection 29
Home Away Draw 29
Total Goals 29
Correct Score 30
All Up Home Away Draw (All Up HAD) 30
Complete betting 32
Mark Six ***34***
Self Select / Random Generator 35
Complete betting 36
Banker 38
4. ViewBets **39**
Stored bet / Delete stored bet 39
Enquire bet total 40
5. Information ***41***
Horse Racing / Mark Six / Football / System information 41
Pager alert setting 41
6. Account Management **43**
Transaction history / Recall transaction 43
Telebet A/C withdrawal 44
Telebet A/C deposit 47
Telebet A/C balance 48
Bank balance 49
7. User setting **50**
Privacy setting 50
Language 52
Disclaimer setting 52
Reply messages 53
8. PIM Application **57**
Calculator 57
Lookup 57
Address book 58
Function 58

1. Service Structure



2. User Reminder

Mango Limited does not guarantee messages will arrive at the Hong Kong Jockey Club. Neither Mango Limited nor the Hong Kong Jockey Club shall be responsible for any failure or disruption of this service or any loss or damage resulting therefrom. All transmitted transactions are subject to the Betting Rules of the Hong Kong Jockey Club and / or the Football Betting Rules of HKJC Football Betting Limited and / or the Lotteries Rules of HKJC Lotteries Limited and/or Interactive Services Conditions of use. Copies of the Rules are available on request at HKJC headquarters and any Off-Course Betting Branch.

The issue and usage of MangoSports is subject to the terms and conditions of the Customer Service Agreement between Mango Limited and the user.

A tamper detection system is installed in the MangoSports, The device will be permanently damaged if the case is forced to open.

Mango Sports PIN

The six-digit exclusive PIN (Personal Identification Number) will be generated by the Hong Kong Jockey Club (HKJC) for every successful application. The PIN is used to verify the identity of the user when accessing the HKJC betting service or Telebet account management via MangoSports. The MangoSports PIN is different from your Telebet Security Code (which is used to access your Telebet account via an operator or Multi-Purpose Terminal in the Off-Course Betting Branch). You must take your MangoSports to an Interactive Services Centre of the HKJC for new PIN generation if you lose your MangoSports PIN.

Usage Boundary

- Service is available in the territory of the Hong Kong SAR
- Service is permitted on the race courses and Club facilities of the HKJC
- Service is restricted to the registered MangoSports account holder who is also a Telebet account holder.

Important notes on sending bets

After sending the stored bets, the user must wait for the reply from the HKJC to confirm the bets were accepted before continuing. If no reply message has been received from the HKJC after sending the transaction request, the transaction will be regraded as an unsuccessful transaction. To check the status of previous bets, please use the " Recall Transaction" function or call HKJC Interactive Services hotline 1880.

Loss of MangoSports

Please call Mango Limited immediately (Tel: 7777 7238) if you lose your MangoSports. User also need to call the HKJC Interactive Service (Hotline: 1880) to report the loss and terminate the MangoSports betting service immediately.

Customer Services

Please call HKJC Interactive Service center (Hotline: 1880) for all Telebet Account issues. For the operation of MangoSports, please call Mango Limited customer service hotline (Tel: 7777 7238) or visit www.mango.cc. Please provide the CIT number and MAN number during your enquiry.

Specifications

Main	MPU	32-Bit RISC Processor
	Memory	8Mbyte FLASH / 8Mbyte SDRAM
	Display	Touch Screen, 160x240 dot FSTN (16-Gray level) with EL-backlight
	Input	Stylus, on-screen keyboard, hand-writing recognition
	Size	68 (W) x 106 (H) x 19(D) mm
	Weight	140g
Power	Battery	Rechargeable Li-Polymer 1800mAh 2 days average usage, 60 days standby

Battery Charging

To charge the battery, connect the cradle to AC power supply using the adapter provided and place the MangoSports in its cradle. Please turn on the MangoSports during charging; the normal time for full charge is 3 hours.

Indication of the LED (charging status):

Color	Status
Red	Charging
Red (Blink)	Signal receiving problem
Green	Charge completed
Green (Blink)	Normal
Yellow	Receiving data

MangoSports Introduction



❶ - Power / Backlight Button
press and hold for 5 seconds to power on/off, press shortly for backlight on/off

❷ - Main Menu Button

❸ - Favorite Button

❹ - Lookup Button

❺ - Trackwheel Key
Scrolls a page up /down, executive a function when pressed

❻ - ESC

❼ - RESET
Reset the MangoSports

❽ - LCD Screen

❾ - Antenna

Maintenance

1. Keep the MangoSports clean and dry
2. Use only the supplied stylus to touch the LCD screen
3. Avoid direct sun light, rain or moisture
4. Do not drop or throw the MangoSports
5. Never turn off MangoSports when transmitting or receiving data

Functional Icons

Signal Strength	NO SVC	Out of signal coverage, extending the antenna
		Weak signal
		Strongest signal
		Problem on modem, need repair
	OFF	Modem off, turn on in the "Function" menu
Battery meter		Weak power
		Need recharge
		Battery meter in 3 levels

Services

Press the related icons in the main menu to start the services provided by the HKJC and Mango Limited:

- Horse Racing
- Football
- Mark Six
- Information
- Account Management
- Setting

Main Menu


Signal
Battery
10:28pm
mango
Horse Racing
Football
Information
Mark Six
Main
Setting
Others
MAIN
PIM
Account Management
TCE
Refresh
Previous Page
Bets
TCE S 1:3+5+7
Field
F
Place 3
13/07 12:27
Last Update Time
1 HAPPY EC .. 4.9 1.6-2.0
2 BROSE'S .. 7.2 2.9-5.2
3 GUSCOTT 10 3.0-5.5
4 HARMONY .. 35 13-15
5 MISSION .. 6.3 1.6-2.6
6 DANZIGFI.. 9.0 2.9-5.2
7 SPORT SE.. 2.5 1.3-1.5
Odds
Horse Selection
Scroll Down
C
Amount

Main Menu


Football
Refresh
Previous Page
Sun
13/08 14:27
Last Update Time
Selected match date
1 Arsenal vs Aston Villa
2 Birmingham vs Blackburn
3 Bolton vs Charlton
4 Chelsea vs Everton
5 Fulham vs Leeds
6 Leicester vs Liverpool
7 Bolton vs Charlton
Team
Match no. Selection
Match Selection Shortcut
Scroll Down
Scroll Up
#
返回

3. Betting Services (provided by HKJC)

Main Menu

Horse Racing, Football and Mark Six

Disclaimer
Mango Limited does not guarantee messages will arrive at the Hong Kong Jockey Club. Neither Mango Limited nor the Hong Kong Jockey Club shall be responsible for any failure or disruption of this service or any loss or damage resulting therefrom. All transmitted
Up
Down

Disclaimer

This disclaimer will display every time when you enter HKJC betting services.

Press (Down) to read whole disclaimer. If you want to turn the disclaimer off, please refer to page 52, "Disclaimer Setting".

Disclaimer
damage resulting therefrom. All transmitted transactions are subject to the Betting Rules of the Hong Kong Jockey Club and / or the Football Betting Rules of HKJC Football Betting Limited and / or the Lotteries Rules of HKJC Lotteries Limited.
Up
Ok
Down

Press (Ok) to continue and start betting services

Horse Racing - Quick Start

1 Horse Racing → 2 Race No. Selection → 3 Pool Selection → 4

- Win / Place / WinPlace
- QIN/QIN Place/Q QIN Place/Trio
- Tierce
- Double/Treble/ Six Up
- Double Trio/ Triple Trio
- All Up Win / All Up Place
- All Up QIN / All Up QIN Place / All Up Trio


Select
horses
Single
Multiple
Banker Single
Banker Multiple
Multi-Banker
5
Input
Amount
6
Send
Bets
7
Complete
Betting
Select races
and horses
elect no.
f races
Select
Formula

Horse Racing

① Horse Racing Menu

Please press [Bet] to select race.

② Races Selection

Select the race number.

Information for the race will be shown at the bottom-left corner.

③ Pool Selection

Select Pool, press [▼] to scroll down for other pools.

④ Selection

Win / Place / WinPlace



Select the horse number, press ▼ to scroll down for other horse numbers. After selecting the horse number, press Amount to input amount, then press Send Bet.

Quinella / QIN Place / QIN QIN Place / Trio

Select the horse number, and press ▼ to scroll down for more selections.

For banker selections, first select the horse number, press Banker then select horse numbers for the legs. Press Amount to input the bet amount.

Tierce

Type of Tierce



Select the bet type from Single, Multiple, Banker, Banker Multiple, Multi-Banker.

Tierce - Single

Please select 3 horse numbers in order.
Press ▼ for more selections, then press (Amount) to input amount.

Tierce - Multiple

Please select horse numbers (3 or more) in order.
Press ▼ for more selections, then press (Amount) to input amount.

Tierce

Tierce-Banker

Please select the horse number for banker selection (2 bankers maximums)
Press (Banker); then select the legs. Press (Amount) to input amount.

Tierce - Banker Multiple

Please select the horse number for banker selection (2 bankers max.)
Press (Banker); then select the legs. Press (Amount) to input amount.

Tierce - Multi-Banker (1st Banker)



Select horse number, Press ▼ for more selections (you can select more than 1 banker). Press (Banker) or (Next) to continue.

Tierce

Tierce - Multi-Banker (2nd Banker)

Select horse number, Press ▼ for more selection (you can select more than 1 banker). Press (Banker) or (Next) to continue.

Tierce - Multi-Banker (3rd Banker)

Select horse number, Press ▼ for more selections (you can select more than 1 banker). Press (Amount) to input amount.

Double / Treble / Six Up / Double Trio / Triple Trio

Double/Treble/Six Up

Select horse numbers (you can select more than 1) then press (Next) for the next race.

After inputing all the horse numbers, press (Amount).

Double Trio / Triple Trio

Select horses number for each race (3 or more). Press (Banker) to select banker if necessary (2 banker max.) .Press (Next) for next leg and select horse number again.

Press (Amount) to input amount after selected for all races.

All Up Win / All Up Place

Select the number of races



Please select the number of races.

Select the formula



Please select the formula.

Selection for the 1st race

Select the horse number for the 1st race.
Then press (Next) for the next race.

All Up Win / All Up Place

Select the next race



Select the race, number for the next race

Selection for the next race

Select the horse number, press (Next) to continue until all horses are selected for the race.

Press (Amount) to input amount after completing selections for all races.

All Up Qin / All Up Qin Place / All Up Trio

Select the number of race



Select the number of the race.

Select the Formula



Select the formula

Selection for the 1st races



Select horse number for the 1st race.

Press (Banker) for banker if necessary

Then press (Next) for the next race.

All Up Qin / All Up Qin Place / All Up Trio

Select the next race



Select the next race number.

Selection for the next race

Select the horse number, press (Next) to continue until all horses are selected for the race.

Press (Amount) to input amount after completing selections for all races.

Complete Betting

⑤ Input Amount

Input amount and press (Send Bet) or press (Store Bet) and continue other services.

Store Bets



Press (Ok).

⑥ Send Bets



Press (Send) to send the stored bets

or press (Back) to continue betting.

Complete Betting

Input PIN



Press Enter after inputting the PIN.

⑧ Betting Completed

After the bet is sent, you will receive a reply message from the HKJC.
Press Done and return to main menu.

Football - Quick Start

1 Football → 2 Select match date → 3 Select match No. → 4 Select bet type

- HAD
- Total Goals
- Correct Score
- All Up HAD — Sel nur ma


- Home
- Draw
- Away
Input total Goals
Input Scores
Select formula
Select team
r of
s
5
Input Amount
6
Send bets
7
Betting Complete

Football - Quick Start

① Main Menu

Press (Betting)

② Date Selection



Select match date.

③ Match Selection



Select the match number.

Press ▲ or ▼ to scroll up or down in the match list.

④ Bet Type Selection

Select the bet type



The selected match number will be shown next to the selected match date.

Now select the bet type

Home Away Draw



Select (Home) (Draw) or (Away)

Then press (Amount) to input amount.

Total Goals

Select total goals, then press (Amount) to input amount.

Correct Score



Select the correct scores for the teams e.g. (1:1) (1:2) (2:2)

Press (Next) to scroll down.

Press (Amount) to input amount

Select the number of matches



Select the number of matches.

Formula Selection



Select the formula.

1st Match Selection



Selection for the 1st match.

Press (Next) for the next match.

Next Match Select



Select the match date for the next match.

All Up Home Away Draw

Select match number and select "Home" "Away" or "Draw" for your predicted result.

Press (Amount) to input amount.

Complete Betting

⑤ Input Amount

Input amount then press (Send Bet) or (Store Bet) to continue.

Store Bet



Press (Ok)

⑥ Send Bet



Press (Send) to send bet

or (Back) to continue betting

Complete Betting

Input PIN

Input PIN, then press (Enter) to transmit the bets

⑦ Complete Betting

After the bet is sent, you will receive a reply message from the HKJC.
Press (Done) back to main menu

Mark Six



① Mark Six Main Menu

Go into Mark Six main menu and select (Self Select) (Random Generation) or (View Bets) (Information)

Self Select, Random Generation, View Bets

Self Select

Select Mark Six numbers, then press Next to continue.

(33 numbers maximum)

Random Generation



Enter number of selection, then press Enter to continue.

(Select 6-33 numbers)

Random Generation



Review the generated numbers. Press the selected number to cancel the selection of that number. Select other non-generated numbers if necessary.

Press Next to continue

② Input Amount



Input amount then press (Send Bet) or (Store Bet) to continue.

Store Bet



Press (Ok)

③ Send Bets



Press (Send) to send bet

or (Back) to continue betting

Input PIN



Input PIN, then press (Enter) to transmit the bets

④ Complete Betting



After the bet is sent, you will receive a reply message from the HKJC.

Press (Done) to back to main menu

Banker

Select Banker

Select number(s) as banker(s), then press (Banker)

(5 Bankers maximum)

Legs Selection



Select the numbers then press (Next) to continue

Available combination:

No. of Bankers	No. of Legs
0	33
1	32
2	31
3	30
4	29
5	28

4. View Bets

View Bets



Press (View Bets) in the main menu of Horse Racing, Football or Mark Six

Stored Bets

Select (Enquire) for the total amount of the stored bets. Press (Send) to transmit the stored bets

Delete Stored Bets



Select the bet that you want to delete, then press (Delete).

Note: You can clear any unsent bets which have been stored in this device. Bets which have been accepted by the HKJC' s betting system **cannot** be cleared.

Enguire Bet Total

Input PIN, then press (Enter)

Enguire Bet Total



Press (Back)

5. Information

Horse Racing, Mark Six, Football and System Informat



Provide related information for horse racing, mark six, football and system information. Press the related tab for information.

Press to update the information.

Pager



Show pager message

Pager Alert Setting



Press Information then it will change to system menu.

press Pager Alert Setting

Pager Alert Setting



Select (ON) or (OFF) in the menu, then press (Enter)

6. Account Management

Main Menu

Provide account management services for HKJC Telebet Account and nominated bank account.

Transaction History



Review the transaction made via the MangoSports. Press (Done) to return to the main menu.

Note:
Records shown in the MangoSports are NOT the formal betting records. The MangoSports can store the details of approximately 50 transactions. Bets placed via a Telebet operator will not appear in the MangoSporst transaction history. They will, however, be reflected in the balance given.

Recall Transaction



Recall transactions made on the account.

Press (More) to read more records or

press (Done) back to main menu.

Telebet A/C Withdrawal

Transfer money from your Telebet A/C to your nominated bank A/C*. Two withdrawal types are available:

Online Autopay

(Autopay requires 3 working days to process)

Telebet A/C Withdrawal - Online

Input bank account password, then press Enter

Telebet A/C Withdrawal - Online



Input amount and press Enter

* Your nominated bank account must be with one of the following designated banks: HSBC, Hang Seng Bank, Standard Chartered Bank, Dah Sing Bank or Mevas Bank. For the first time using this function, please perform Telebet account balance checking with your bank card at a Multi-Purpose Terminal in any Off-Course Betting Branch or race course of the HKJC. Withdrawal and deposit amounts are subject to the limits set by the HKJC and respective bank.

Telebet A/C Withdrawal - PIN

Input the PIN then press (Enter)

Telebet A/C Withdrawal - Complete (online)

Press (Done) to confirm the details.

Telebet A/C Withdrawal - Autopay



Input amount and press (Enter)

Telebet A/C Withdrawal - PIN

Input PIN and press (Enter)

Telebet A/C Withdrawal - Complete

Press (Done) to confirm the details.

Telebet A/C Deposit - Bank Account Password

Transfer money from your nominated bank account to your Telebet account. Input bank account password, then press (Enter)

Telebet A/C Deposit - Amount



Input amount, then press (Enter)

Telebet A/C Deposit - PIN

Input the PIN then press (Enter)

Telebet A/C Deposit



Press (Done) to confirm the details.

Telebet A/C Balance

Input the MangoSports PIN and press (Enter)

Telebet A/C Balance



Shows the balance of your Telebet account, Press (Done) to return to the main menu.

Bank A/C Balance

Check the nominated bank account balance. The current and available bank balance are displayed.
Input bank account password, then press Enter

Bank A/C Balance

Input the PIN, then press Enter

Bank A/C Balance

Shows the balance of your bank account, Press Done back to main menu.

7. User Setting

User Setting Main Menu



Change settings for the MangoSports

Privacy Setting



This is the security setting for MangoSports. You need to input a 3 digit privacy key to activate MangoSports every time you use it if the privacy setting is turned on. MangoSports will be locked if the privacy key is input wrongly consecutive 3 times. To unlock it, MangoSports will ask for the MangoSports PIN. The privacy setting will turned off automatically if the MangoSports PIN is correct. To turn on the privacy setting press (On) and press (off) to turn it off.

Privacy Setting - Set privacy key

Input the 3 digit privacy key and press (Enter)

Privacy Setting - Set privacy key

Privacy key setting is complete, Press (Ok) to return to the menu.

Privacy Setting - Privacy key cancel

Input privacy key and press (Enter)

Privacy Setting - Set privacy key

Privacy key cancelled, press (Ok) to return to the menu

Language

Select desired language

Language



Language change completed, Press (Ok) to return to the main menu

Disclaimer Setting



If the disclaimer setting is turned on, the disclaimer will be displayed every time you go into the betting menu.

Press (Off) to turn the disclaimer off.

Reply Messages - Horse Racing

Messages	Details
Insufficient Selections	Select correct no. of horses or number according to your bet type before press "Amount"
Too Many Bankers	Too many banker are entered. Select correct no. of bankers according to your bet type. Re-enter the valid number of bankers.
Invalid Meeting	The selected meeting not yet ready for betting, please try again later.
Pool Closed	Selected pool has been closed for betting
Horse XX Scratched	Selected horse scratched

Reply Messages - Football

Messages	Details
New Information Will Be Updated	Football information in MangoSports will be update
Insufficient Selection	Select correct no. of match and teams according to your bet type
Maximum Amount is $XXX	Excess the maximum limit allowed by HKJC, re-enter the amount
Over Daily Max inv for FB 9	User had excess the daily maximum betting limit, the Club will not accept any more bets within the same day
Pool Not Available	The selected pool is not available, please try later

Reply Messages - Mark Six

Messages	Details
Invalid Total Numbers	The number of selections for the Mark 6 exceeds the valid limit (6 to 33 numbers), re-enter the valid numbers of selection.
Insufficient Selections	The number of selection for Mark 6 is not enough. Re-enter the valid numbers of selection.
Too Many Bankers	Too many bankers, re-enter the valid numbers of bankers
Pool Not Available	The selected pool is not available, please try later

Reply Messages - Account Management

Messages	Details
Invalid Input	Bank PIN not correct, please re-enter the PIN (at least 4 digits)
Minimum amount is $xxx	Entered amount should not less than the minimum limit $xxx
Maximium amount is $xxx	Entered amount should not greater than the maximium limit $xxx
Insufficient Balance	Insufficient funds for betting, withdrawal or deposit; deposit funds into the account. Transfer sufficient amount to your account.
No Details	No transaction records for Telebet A/C when check by the "Recall Transaction" function
All Pools Refund	The invested race(s) abandoned and all investment for that race(s) refunded
Refer to Bank	Fund transfer request rejected by the bank, please contact your bank
Too Many Withdrawals	The number of withdrawals exceeds daily max number of on-line withdrawals limit. Perform withdrawal again on the following working day.
Bank PIN Error	Bank PIN not correct, re-enter or contact your bank
Bank System Fault	Bank system fault, try again later
EPS System Busy	EPS system is busy, try again later
Access Not Permitted	The account is disabled by the Club, please contact CIT hotline
Bank Card Not Registered	No debit card details in the Telebet system, please check the balance of the nominated bank at the FET terminal with your debit card
Invalid Bank Card	The debit card used is not a member of the EPSCO, please nominate a bank account which is a member of EPSCO

Reply Messages - User Setting

Messages	Details
Invalid Privacy Key	The privacy key is not correct
Invalid Privacy Key. Device is locked	MangoSports locked due to the privacy key wrongly entered for consecutive 3 times. To unlock it, MangoSports will ask for thePIN and verify with HKJC and the privacy setting will be turn off automatically if the PIN is correct.
Not Privacy On	User set privacy setting off when privacy setting is not on
Already Privacy On	User set privacy setting on when privacy setting already on

Reply Messages - General

Messages	Details
PIN Error	The entered PIN is not correct, re-enter the PIN again
CIT Service Not Available	The CIT service is closed, please use the MangoSports during CIt business hours
Minimum amount is $xxx	Entered amount should not less than the minimum limit $xxx
Maximium amount is $xxx	Entered amount should not greater than the maximiumlimit $xxx
Bets exist in buffer, please choose View Bet to send bet or delete	Choose View Bet to send or delete bets
Too many Bets, please send bets before entering new bets	Too many bets stored in buffer, please send bets before entering new bets
Unable to connect to network. The Information displayed may not be up to date. Please check modem or try again later	MangoSports cannot connect to network, please check modem or try again later
Communication Error. Do RECALL Transaction to Check Status	Cannot receive reply after send instruction, please do RECALL Transaction to check if the request was accepted.
Communication Error, Please Try Again	Cannot receive reply after send instruction, please try again
CIT Disabled Contact the Club	Your MangoSports betting services is disabled by HKJC, please contact HKJC Interactive Services Hotline:1880
System not ready	The Telebet system is not ready for service, try again later
Battery Low, Please recharge battery	Battery low, please recharge, MangoSports need 3 hours for full charge.

9. PIM Application Program

PIM Application Main Menu



MangoSports also included applications:

- Address Book
- Function
- Calculator
- Lookup
- Internet

Calculator

Included 4 functions:

- Calculator
- Scientific Calculator
- Measures
- Exchange Rate

Lookup



Search data in address book by name, phone number or other information.

Address Book



Address book will sort data in alphabetic order. User can store data in 3 group:

- Business
- Personal
- Unfiled
- All (show all groups)

Press on the top-right corner to select or edit group.
Press on the item to read details.

Address Book - Create and Edit Address

❶ Press (New) to create new address or (Edit) to edit address

❷ Enter address and details

❸ Press (Done) when finish

The " Name" field cannot be empty

Function

Press the related function icons to go into the menu, it included the following functions:

- Time	- Sound	- Favourite
- Security	- Calibrate	- Memory
- Modem	- Terminal	- Keypad
- Group	- Modem Test	- General

 All Right Reserved by Mango Limited

Information in this booklet may be extended, changed or deleted without separate announcement. No portion of this booklet may be reproduced in any form, or by any means, without the prior written permission from approval of Mango Limited and its subsidiaries or other affiliates.

Mango Limited
32/F., Tower 2, Metroplaza,
Kwai Fong, N.T., Hong Kong
Tel: 77777-238